

# Code Lists

## Listes de Codes

### Lista de Códigos

#### TV / Téléviseur

ABEX.....	69913, 64911
ACCURIAN.....	91814
ACER.....	16317, 59114, 42919
ADC.....	33719, 65312
ADVENT.....	91019, 71014, 99715, 50411
AFFINITY.....	07819
AFTRON.....	01219
AIKO.....	63511
AIWA.....	40411, 66111
AKAI.....	97817, 09619, 90117, 43514, 94219
ALLERON.....	54711
AMTRON.....	79513
AMW.....	75214, 64013
ANAM NATIONAL.....	78613, 57611, 79513, 58211, 49219
AOC.....	31811, 19819, 40413, 53313, 31612, 52713, 33411, 33412
APEX.....	75217, 54214, 42113, 76314, 47111
APX DIGITAL.....	60113, 84715, 06016, 39019
ARIO.....	39019
ATVIO.....	21711, 63315, 64615, 38111
ATYME.....	52013
AUDIOVOX.....	79513, 75512, 86413
AURIA.....	31612, 33412
AURORA.....	46014
AURVIO.....	46513, 57014
AVENTURA.....	88518
AVERA.....	68515
AVOL.....	87217, 89115
AXESS.....	41811
AXION.....	84315
BANG & OLUFSEN.....	52401
BELL & HOWELL.....	26618, 65312, 98215
BENO.....	87813, 95719, 31919, 80014
BLUE SKY.....	98314, 95017
BOE.....	89013, 19819
BOEVA.....	72015
BROOKWOOD.....	43411
BROKSONIC.....	81017, 65813, 57812, 75614, 55711, 54411
CCE.....	95017
CELERA.....	86718, 42113
CENTRIOS.....	82614
CETOMER.....	83314, 40412
CETRONIC.....	78613
CHANGHONG.....	01618, 72117
CHARTER COMMUNICATIONS.....	80415
CHIMEI.....	24912
CIELO.....	30812
CINERAL.....	63511, 95017
CITIZEN.....	58412, 60112, 93115, 78613, 79513, 63511
CLASSIC.....	46311, 04616, 78613
CLP.....	43311
CLP CLASSIC.....	43411, 79914
COBY.....	13011, 77617, 96315, 52411, 52211, 61611, 77912
COLORTYME.....	33719
COMWAVE.....	32611
CONTEC.....	54312, 56511, 78613, 79513
CONTEX.....	20011
CORNEA.....	66712
CRAIG.....	19311, 24912, 23211, 78613, 79513
CROSLEY.....	19711, 56011, 79914
CROWN.....	78613, 79513
CRYSTAL.....	72117
CTX.....	55411
CURTIS.....	11711, 47913, 68515, 79016, 80517, 64615, 20011
CURTIS INTERNATIONAL.....	07819, 47913, 68515, 79016, 80517, 91118
CURTIS MATHES.....	90614, 17411, 58012
CYBERVISION.....	58412, 26618, 98215, 66611
DAEWOO.....	74412, 42211, 84014, 78613, 68912, 63511, 33411, 85817, 90214
DAYTRON.....	43411
DELL.....	40211, 61211, 65411, 92815, 95017
DEVANT.....	94818, 27911, 05319
DIAMOND VISION.....	59612, 86115, 54911, 57111
DIGHOME.....	71415, 37811
DIGIMATE.....	63112
DIGISTAR.....	42214, 71014, 65411, 78613
DIGITAL.....	83618
DIGITOR.....	33113
DISNEY.....	81017
DISTAR.....	84218
DSE.....	22612
DUKANE.....	37219, 67412

LENSON.....	66116
LETV.....	56614, 67115
LG.....	31311, 52412, 63913
LIQUIDVIDEO.....	84315, 17517
LODGENET.....	65312, 98215, 80714, 08415
LOEWI.....	56011
LOGIK.....	54311, 56511, 79513, 00615
LUCE.....	70514
LXI.....	55514, 58012, 53112, 40411, 26618, 60112, 98215, 56011
MAG.....	40114, 58414
MAGNASONIC.....	54211
MAGNAVOX.....	95017, 42812, 88518, 25011, 42513, 48111, 82615, 51011, 63011
MAGNAVOX (ROKU TV).....	44211
MAJESTIC.....	98215
MARANTZ.....	33412, 53811, 56011
MATSEIG.....	39111
MATSUSHITA.....	39111
MAXENT.....	27117, 59912
FISHER.....	26618, 72112, 66011
FLUID.....	70013
FUJICOM.....	76615
FUJITSU.....	54711, 74012
FUNAI.....	88518, 29311, 25011, 48111, 40411, 54711
FURRIOR.....	47414, 27911
FUTURETEC.....	78613, 79513
GATEWAY.....	20111, 59912
GE (GENERAL ELECTRIC).....	50115, 14951, 55514, 42113, 87215, 73814, 90005, 00615
GENERAL INSTRUMENT.....	39019
GFM.....	88518, 29311, 03419, 25011
GIBALTER.....	74916, 53511, 53911
GLOBALSTAR.....	49011
GOLDI.....	89013
GOLDSTAR.....	55514, 40411, 33411
GPX.....	24611, 21311, 46911
GRADIENTE.....	43411, 81214, 92114, 09215, 65311
GRUNDIG.....	37911
GUESTVISION.....	53311
GVISION.....	88113
HAIER.....	56013, 12511, 60914, 11711, 55514, 43912, 54513, 77612
HAIER(ROKU TV).....	44211
HALLMARK.....	55514
HANNSPREE.....	15811, 26812
HAUPPAUGE.....	29811, 31912, 47811, 53811, 33411
HAVERMUY.....	22511
HELLO KITTY.....	78212
HIDEAR.....	68211
HISENSE.....	35611, 44211, 67614, 78115, 59413
HISENSE (ROKU TV).....	44211, 55712
HITACHI.....	13611, 44913, 49012, 37811, 61513
HITACHI (ROKU TV).....	44211
HKC.....	47414
HKPRO.....	38811
HP (HEWLETT PACKARD).....	38013, 83013
HYUNDAI.....	66213, 63811, 01115
IKON.....	17711, 94219, 85818
ILO.....	28118, 93115, 89514, 56811, 94215, 05816, 03715, 88518
INFINITY.....	51011, 56011
INFOCUS.....	35912, 38618
INITIAL.....	62213, 89514, 74213
INSIGNIA.....	28911, 12219, 49412, 28511, 06191, 07216
.....	69212, 89713, 70017, 39512,
.....	45013, 69613, 82615, 61312
INTEC (ROKU TV).....	12219, 44211
INTEC.....	38011
INTEQ.....	74916, 53511, 53911
INTEQ.....	11711
INTEQ.....	56011
INTEQ.....	25811
INTEQ.....	98215, 90015, 49219, 33411
JENSEN.....	69212
JOCCEL.....	67211
JVC.....	11719, 99717, 00218, 48812, 48611, 77213, 87314
JVC (ROKU TV).....	44211
KALLEY.....	01115
KAWASAKI.....	47011
KAWASHO.....	56111
KC.....	20611
KDC.....	40114, 58414
KEC.....	78613
KLH.....	42113
KLOSS NOVABEAM.....	68413
KNOLL SYSTEMS (ZENITH).....	74916
KOGI.....	88113
KONKA.....	45013, 66213, 32319, 22218, 96514
KREISEN.....	97619
KTC.....	27019
KTV.....	15311, 54312, 88114, 78613, 79513
KURAZAI.....	65312
KWORLD.....	72813
LASONIC.....	86115, 54911
LEADER.....	96319
LEEGE.....	10011
LEGEND.....	68515, 71014
LENOVO.....	90919

PULSAR.....	74916, 53511, 53911
PYLE.....	68016
PYLE HOME.....	68016
QFX.....	41811
QUASAR.....	87215, 64812, 56011, 51913, 39011
RADIO SHACK.....	55514, 47811, 40411, 26618, 98215, 54311, 56511, 79513, 00615
RCA.....	66114, 44712, 54113, 11711, 58915, 69416, 36412, 04719, 26411, 22511, 33012, 44613, 55213, 65714, 43912, 61513, 67013, 90214, 79712, 32111
RCA (ROKU TV).....	54211
REALISTIC.....	55514, 57512, 47811, 40411, 26618, 98215, 78613, 79513, 79515
REVOLUTION HD.....	93819
RIVIERA.....	90614, 50613
ROKU TV.....	44211
ROWA.....	53815
RUNCO.....	48213, 30611, 43711, 70713, 01815
WESTINGHOUSE (ROKU TV).....	44211
WHITE-WESTINGHOUSE.....	81017, 53212, 40411, 90214
WINDSOR.....	37811
WYSE.....	34413
XIAOMI.....	21012
XOCECO.....	14011, 14811, 16611
YAMAHA.....	33411, 79515
ZENITH.....	64512, 53014, 43311, 40411, 51712, 95216, 51011, 15117, 54411, 57011, 64311, 63511, 85913, 66611
ZUTEST.....	49611

VICTOR.....	77213, 64811
VIDEOCON.....	97914
VIDTECH.....	55514, 33411
VIEWSONIC.....	47312, 92419, 12911, 23512, 34413, 45914, 56415, 12311, 23812, 10111, 10511, 59912, 31612, 67412, 33412
VIMAX.....	54015
VIORE.....	68411, 24912
VISION QUEST.....	80213, 44384
VIVITEK.....	15641
VIZIO.....	35011, 40412, 80016, 20111
WARDS.....	74916, 55514, 81015, 47811, 71013, 98215, 54711, 90155, 56011, 33411
WAYCON.....	70416
WBOX.....	12618, 23219, 45211
WESTINGHOUSE.....	58813, 31912, 69314, 11711, 68515, 48213, 30611, 43711, 70713, 01815
WESTINGHOUSE (ROKU TV).....	44211
WHITE-WESTINGHOUSE.....	81017, 53212, 40411, 90214
WINDSOR.....	37811
WYSE.....	34413
XIAOMI.....	21012
XOCECO.....	14011, 14811, 16611
YAMAHA.....	33411, 79515
ZENITH.....	64512, 53014, 43311, 40411, 51712, 95216, 51011, 15117, 54411, 57011, 64311, 63511, 85913, 66611
ZUTEST.....	49611

#### Projector / Proyector / Projecteur

3M.....	46284, 51985, 30483, 45584, 78487, 43784, 65186, 60985
AAXA.....	47084
ACER.....	45283, 14081, 21981, 32582, 32882, 29581
ADJ.....	21381
AEHR.....	35182
ASUS.....	12181
AVERMEDIA.....	36583
AVIO.....	55684
BARCO.....	65186
SOANY.....	53485, 37683, 48584, 59384, 55285, 33883, 16481, 85488, 12581, 65485, 67385
BOMAKER.....	56884
BOXLIGHT.....	35083
CANON.....	20582, 19381, 29181, 30082
CASIO.....	25982, 34683
CHRISTIE.....	32183, 58784, 69685, 25681, 25081, 36982, 47583, 58084, 35282, 24681, 78286
CIBEST.....	57684
COCAR.....	35182
COOAU.....	45383
COOLUX.....	26482
SPELER.....	41313
SQUAREVIEW.....	88518, 93115
STAR SAT.....	80118, 17211, 85114
STARLITE.....	79513
ONN.....	57513, 43612, 32011, 60717
ONN (ROKU TV).....	44211
ONWA.....	78613, 79513
OPTIMUS.....	64812, 39011
OPTOMA.....	46114
OPTONICA.....	47811, 55411
ORION.....	21311, 81017, 53511, 53911
PALSONIC.....	73717
PANASONIC.....	39011, 39811, 51913, 60513, 79515
PANDA.....	18911, 18411
PARK.....	25811
PEERLESS.....	18918
PENNEY.....	55514
PHILCO.....	25011, 41212, 63214, 76813, 92815, 01115, 33411, 52814
PHILIPS.....	62414, 17419, 33412, 06918, 73915, 84416, 95017, 44211, 21319, 43911, 48111, 82615, 88518
PHILIPS (ROKU TV).....	44211
PHILIPS-MAGNAVOX.....	56011, 69411, 73915, 86815, 51011
PIONEER.....	69913, 53714, 73513, 53811
PIVA.....	86914
PIXEL.....	43411
PLANAR.....	40413, 75812
POLAROID.....	89013, 33211, 68515, 24912, 40114, 58414, 42113, 20011, 65014, 94016, 43319, 07015, 67211, 16611
PORTLAND.....	21412, 32913
PRECISION.....	63511, 33411
PRIMA.....	74916
PRINCETON GRAPHICS.....	59611, 55411
PRISM.....	01117
PROMAC.....	26711
PROSCAN.....	47414, 11711, 34211, 07819, 93218, 20011, 35611, 07017, 01815, 79712, 69416
UNIVERSAL.....	42611, 90015
UPSTAR.....	27411, 51914
VENTURER.....	51611, 65911
VESTEL.....	71415
VICTOR.....	77213, 64811
VIDEOCON.....	97914
VIDTECH.....	55514, 33411
VIEWSONIC.....	47312, 92419, 12911, 23512, 34413, 45914, 56415, 12311, 23812, 10111, 10511, 59912, 31612, 67412, 33412
VIMAX.....	54015
VIORE.....	68411, 24912
VISION QUEST.....	80213, 44384
VIVITEK.....	15641
VIZIO.....	35011, 40412, 80016, 20111
WARDS.....	74916, 55514, 81015, 47811, 71013, 98215, 54711, 90155, 56011, 33411
WAYCON.....	70416
WBOX.....	12618, 23219, 45211
WESTINGHOUSE.....	58813, 31912, 69314, 11711, 68515, 48213, 30611, 43711, 70713, 01815
WESTINGHOUSE (ROKU TV).....	44211
WHITE-WESTINGHOUSE.....	81017, 53212, 40411, 90214
WINDSOR.....	37811
WYSE.....	34413
XIAOMI.....	21012
XOCECO.....	14011, 14811, 16611
YAMAHA.....	33411, 79515
ZENITH.....	64512, 53014, 43311, 40411, 51712, 95216, 51011, 15117, 54411, 57011, 64311, 63511, 85913, 66611
ZUTEST.....	49611

#### Digital TV Tuner / Syntonneur de Télévision Numérique / Sintonizador de TV Digital

ACCESS HD.....	11841, 97049, 45244
ADB.....	81747, 44042, 16841
ALINK 101.....	81248, 29942
ALPHA DIGITAL.....	97049, 45244
AMINO.....	55643
AMTC.....	97049, 45244
APEX.....	15641
APEX DIGITAL.....	15641
APPLE.....	25742
ARRIS.....	27141
ARTEC.....	70747, 34743
AT&T.....	27542
CADENCE.....	23242
CASIO.....	31543
CHANNEL MASTER.....	80848, 39441, 41044
CINNINNATI BELL.....	40742
CISCO.....	35342, 24342, 27542, 16341, 61844
COBY.....	77047, 36243
OPTIMUS.....	12021
ORION.....	35023, 12121, 10621
PANASONIC.....	88728, 11321
PHILIPS.....	53325, 75827, 19321, 71027, 17421, 51225
PHILIPS-MAGNAVOX.....	71027, 81128
PIONEER.....	19821, 48424, 15821, 47024, 84828, 21622
PROSCAN.....	14621
QUASAR.....	94729, 17921, 12521, 12021
RADIO SHACK.....	22222, 30423
RCA.....	47024, 13221, 18821, 56025, 43724
REALISTIC.....	97829, 92029
SAMSUNG.....	20822, 93429, 47024, 80628, 41924, 52425, 34623, 32123



PORTLAND	26151	05756
POWER ACOUSTIK		47951
PROLINE	16851	34452
PROSCAN		31751
PROTRON		21651
PYLE	27452	27959
RADIO SHACK	64455	06858, 70855, 08457, 48553
RCA	75157	16051, 14951, 58354, 34452, 31751, 06858, 70855, 08457
REGENT		57453
REOC		39751
RIO		83254
RJ TECHNOLOGY		82256, 56052
ROSEN		17359, 54252
ROTEL		32152
SABA		64455
SAMSUNG	14451	25352, 17651, 69255, 37652, 13959, 66754, 36651, 37451, 96457, 18559, 29359, 67653, 70454, 82455, 54653, 95455
SANSUI		23851, 68253
SANYO	24351	58053, 52653, 08457, 50751, 16257
SEARS		27651, 68253, 71954
SEG		22951
SELECTRON		72955, 49352, 72255, 32551, 65954, 87356, 30151, 66153
SEMP		55454
SENSORY SCIENCE		33151
SHARP	17151	28652, 39153, 49554, 40151, 39959
SHERWOOD		45953, 95156
SHINCO		53253, 86055
SHINSONIC		53253, 86055
SICHLER-PEARL		53253, 86055
SONIC BLUE		40253
SONY	64656	63755, 55952, 42654, 53155, 65753, 42151, 62153, 61151
SOUNDSTORM		27452, 35951
SOVA		91256
SPECTRONIQ		17051
SUNGLE		51154, 71355
SUPERSCAN		27651, 71954
SUPERSONIC	54654	34052, 34353, 56355
SV2000		27651, 71954
SVA		55354
SYLVANIA	26051	27651, 34151, 58053, 63853, 71954, 15458, 53052, 75554, 84655, 16257
SYMPHONIC	26051	61855, 27651, 42453, 34151, 71954, 15458, 53052, 16257
TASCAM		13351, 32152
TCL		85255
TEAC		82258, 08457
TECHNICS		31451
TECHWOOD	35852	44952, 47252, 54453, 42551
TERAPIN		60854
TEVION	85757	28451, 55454, 33352, 75755, 39751, 34851
THETA DIGITAL		82258
TIVO		53954, 44652
TOSAKI		85757
TOSHIBA	29451	26752, 25352, 36853, 47354, 58255, 14351, 14751, 91959, 72753, 40754, 23151, 72551, 30551, 07058, 46251, 68253, 68954
TREDEX		68954
TRUTECH		46852, 03357, 50351
UNITED		08457
URBAN CONCEPTS		29451
VENTURER		27052, 76254, 08457
VIOS		96258
VIZIO	74055	51652, 51551, 51951, 62552, 73453, 84954
WESTINGHOUSE		61151
WHARFEDALE		34051
WHITE-WESTINGHOUSE		26051, 15458
XBOX		14951, 57455, 17558, 28159
XENIUS		55454
YAMAHA	26752	35852, 66955, 08258, 31451, 42752, 40352, 45051, 77054
YAMAKAWA		41254, 22951, 22451, 38951
ZENITH	98658	04957, 61551, 94855, 83254
ZUTEST		02959

KENWOOD		66952, 77553
LG	53451	62852, 58151, 52151
MAGNAVOX		71653, 64752, 25058
MAJESTIC		01856
MARANTZ	57551	88054, 65252, 76753
MEMOREX		82554, 70653
MITSUBISHI		16061
ONIKYO		58551
ONIN		69552
OPPO	86854	97355, 83653, 87552
PANASONIC		59851, 57951, 92055
PHILCO		87254, 98855
PHILIPS	98155	59151, 90955, 14457
PHILIPER		55651, 96655
POLAROID		65152
POPCORN HOUR		89354
PROSCAN		14951
RCA		86154
SAMSUNG	94554	60452, 55051, 67352, 78853, 12357, 30159, 72052
SANYO		64752
SHARP		97755, 24458, 52751
SHERWOOD		71953, 07156
SONY		05055, 60052, 75353
SYLVANIA		88754, 03556
TCL		36559
TOSHIBA	93055	59051, 80954, 13957
VIORE		91555
VIZIO		77153, 08256, 63652
YAMAHA		89454, 18657
ZUTEST		91455

**Cable Set Top Box / Boîtier décodeur pour câble / Convertidor para Cable**

**Satellite Set Top Box / Boîtier décodeur pour satellite / Convertidor para Satélite**

ABC		01949, 32941, 66643, 43641
ACCESS HD		53344
ADB		81747
ADELPHIA		43144, 34841
ADTH		53542
ALLEGRO		76245
ALTICE		25441
AMERICAST		29241, 23241
AMINO		55643
AMPER		44243
ANTRONIX		41241, 50342
APEX		02848
ARCHER		41241, 67443, 88045
ARION		47642
ARRIS	39242	53043, 47942, 48242, 59743
ASTOUND BROADBAND		85346
ASTRO		93846
AT&T	35741	37442, 58543, 58742
AZBOX		64644
BEIN		71145
BELL	53043	34542, 64945, 55841, 59841
BELL EXPRESSVU		64945, 78445, 61843
BELL SOUTH		23341
BENDBROADBAND		29241
BRIGHT HOUSE		43144, 25441, 65642
BUCKEYE		30142
CABLE ONE	54044	65246, 29241, 25441, 65642
CABLEMAS		43144, 01949
CABLETENNA		41241
CABLEVIEW		41241
CABLEVISION	43144	39242, 25441, 35441, 33541, 80845, 65642
CASI		93445
CEBRIDGE		29241
CENTURY		51441, 88045
CETOMER		62145, 57142
CHAMP		69744
CHANNEL MASTER	74646	39441, 50243, 63243, 45941, 44041
CHAPARRAL		79244
CHARTER COMMUNICATIONS		25441, 27141
CHARTER DIGITAL		57344
CHEYENNE		79244
CINCINNATI BELL		40742
CISCO	33841	43144, 37442, 64245, 34541, 58543, 61844, 65642
CITIZEN		88045
CLARO		26541
COGECO		39242, 34541
COMCAST		34541, 25441, 58144
COMTRONICS		76945
CONFLUENT		51243
CONSOLIDATED COMMUNICATIONS		68344, 79245
COPTEC		74545
COOLSAT		62342, 93445
DYNEX		55151, 61252
FUNAI		64752
HITACHI		75253
HP(HEWLETT PACKARD)		29558
HUMAX		83246
INSIGNIA		59551, 66652, 02356, 69052
JBL		51854
JVC		81554

**Video - Blu Ray / Vidéo - Blu Ray**

ALLEGRO		56951
ATVIO		76053, 87654
BLACK WEB		79453
BUSH		99655
CINEVISION		62852
DEAWOW		54251, 54651
DENON	53251	90255, 74153
DISNEY		56451
DYNEX		62342, 93445
FUNAI		55151, 61252
HITACHI		64752
HUMAX		83246
INSIGNIA		59551, 66652, 02356, 69052
JBL		51854
JVC		81554

67944	53444	45842	60244
DISHPRO		64945, 78445, 56542, 40141, 28848	
DMT		68245, 39142	
DRAKE		74144, 68043	
DREAMBOX		59341, 60842	
DX ANTENNA		23949	
EASTERN	43144	76143, 25441, 26041, 95747	
EASTLINK		85346	
ECHOSPHERE		65642	
ECHOSTAR	51244	44343, 55844, 66345, 33742, 64945, 34341	
EMTEC		88544, 99045	
ENTONE		63145	
ENVISION		24441	
EVERQUEST		76945	
EVOLUTION	54345	20441, 64245, 35941	
EXPRESSVU		64945, 78445, 61843	
FORTEC STAR		52443, 49741, 55042, 77544	
FRONTIER		76143, 65642	
FUJITSU		46241	
GARRARD		88045	
GC ELECTRONICS		50342	
GE (GENERAL ELECTRIC)	49441	45541, 57142, 81745, 42941	
GEMINI		87846, 63944, 72344	
GENERAL INSTRUMENT		62145, 56842, 65143, 87645, 46641	
GENERAL INSTRUMENT (GI)		29241	
GEOSATPRO		91848	
GLOBALSAT		33041	
GLOBECAST		65444, 48941	
GO VIDEO		71443	
GOI		64945	
GOLDSTAR		82945	
GOODMIND		81745	
HAMILIN		89445, 66643	
HFC		59242	
HILTON		77045	
HITACHI		62145, 56842, 43641, 54942	
HNS		62145	
HOMEZUS		34541	
HOMECAST		17749, 36141	
HOMEWORX		49742	
HTS		64945	
HUAWEI		34541	
HUGHES NETWORK SYSTEMS		48643, 54141	
HUMAX		40541, 54141	
ILLICO		43144	
ILO		59342	
INFOCUS		31342	
INSIGHT		25441, 58144	
INSIGNIA		52644	
IVIEW		50343	
JASCO		88045	
JERROLD	66643	32941, 49941, 43641, 47441	
JVC		08648	
JYNBOX		77246	
KAON		77446	
KENWOOD		78944	
KNOLOGY		39242, 25441, 58144, 43144	
KOOLCONNECT		55643	
KWORLD		72813	
BELL		37442	
LAYERS		98645	
LG		62145, 66042	
LITEON		59342	
LUXOR		06447	
MACOM		43041	
MAG		42843, 46442	
MAGNAVOX		43342, 44442, 43141, 80145	
MANHATTAN		25241	
MEDIACOM		62845, 25441, 34541, 65642	
MEDIAONE		39242, 29241	
MEDIASONIC		37042, 69744	
MEDION		59342	
MEGACABLE		39242	
MEMOREX		30941	
METROCAST		39242	
METROCAST CABLEVISION		34541	
MICROGEM		52145	
MICROYAL		34541	
MIDCONTINENT COMMUNICATIONS		34541	
MITSUBISHI		87744	
MOTOROLA		28241, 48943, 40743, 95747, 34541, 48142, 44141, 39242	
MOVIE TIME		07448	
MOVISTAR		39241	
MOXI		47942, 27141, 61645	
MXQ		38241	
MYRIO		26141	
NEGRAVISION		26041	
NEOSAT		49441, 54642	
NEOSAT		70144	
NEOTION		24341	
NET		60045, 26041, 73544, 51941	
NET DIGITAL		60045	
NETGEM		37533	
NEXT LEVEL		29641	
NOVAPLEX		98347, 69243	
NOVUS		46843, 65642	
NOW TV		97346	
NSC		07448	
OAK		27641	
OL		37641	

OMEGA		24941
OMEGASAT		24941
OPENBOX		68245, 39142
OPTIMUM		43144, 25441, 33541
ORASAT		39349
OXFORD		24741
PACE	43144	76143, 25441, 26041, 95747
PANASONIC		74445, 96947, 34541, 85745, 48441, 82245
PANSAT		02349
PARAGON		09941
PHILCO		55144
PHILIPS	87744	12641, 54745, 32441, 29749, 60843
PHILIPS-MAGNAVOX		44442, 67445, 54843, 43141, 80145
PHILO		27141
PINNACLE		19448, 59541, 59941
PIONEER		25441, 66943
POLAROID		55041
PRIME		59544
PRIMESTAR		43543
PROSAT		81345, 86545
PROSCAN	42941	49441, 57142, 71344
PULSAR		30941
QUASAR		30941
RADIO SHACK		67445, 54843, 76245
RCA		41043, 71444
RCN		65642
REALISTIC		52742, 50342, 95546
REGENCY		85346
REMBRANDT		43641
ROGERS	25441	45443, 56944, 65642
RUNCO		30941
SAMSONIC		86445
SAMSUNG	43144	32243, 58143, 55141, 54141
SANSONIC		71147
SASKTEL		34542
SCIENTIFIC ATLANTA		43144, 29241, 34541, 98347, 41542, 07747
SERVICE ELECTRIC		34541
SHARP		96648, 60542
SHAW		27141, 34541, 48142, 65642
SHAW DIRECT		77943
SIERRA II III		79244
SIGNALMAX		74945
SIGNATURE		43641
SKY		48643, 21742, 40043, 51644, 28549, 38642, 38942, 49543, 50044
SKY HD		48643, 54141
SKY NETWORK	28549	73843, 84344, 95245, 51341
SKYBOX		68245
SKYMASTER		56845
SL MARX		76945
SONICVIEW		08648
SONY	71845	65344, 83245, 54642, 79644, 04347, 55541, 77643
SPRINTRM		39242, 43144, 19249, 31241
SPRUCER		48441
STANDARD		49341
STAR CHOICE		29641, 43543, 84045
STAR SIGHT		18248, 70144
STAR TRACK		45841
STARCOM		16848, 66643
STARGATE		76945
STS		23949
SUDDEN LINK		17141, 39242, 25441, 34541, 61144, 83246, 65642
SUPER GUIDE		44841
SUREWEST		23841
SYLVANIA		43144, 44841
TANDY		82944
SEAGATE		45341
SHARP		62144, 34541
TELEFONICA		37042, 69744
TELEGENIC		72345