

Code Lists

Listes de Codes

Lista de Códigos

TV / Téléviseur	
ABEX.....	69913, 64911
ACCURIAN.....	91814
ACER.....	16317, 59114, 42919
ADC.....	33719, 65312
ADVENT.....	91019, 71014, 99715, 50411
AFFINITY.....	07819
AFFRON.....	01219
AIKO.....	63511
AIWA.....	40411, 66111
AJAI.....	97817, 09619, 90117, 43514, 94219
ALLERON.....	54711
AMTRON.....	79513
AMW.....	75214, 64013
ANAM NATIONAL.....	78613, 57611, 79513, 58211, 49219
AOC...31811, 19819, 40413, 53313, 31612, 52713, 33411, 33412	
APEX.....	75217, 54214, 42113, 76314, 47111, 60113, 84715, 06016, 39019
APEX DIGITAL.....	39019
ARIO.....	68515
ATVIO.....	21711, 63315, 64615, 38111
ATYME.....	52013
AUDIOVOX.....	79513, 75512, 86413
AURIA.....	31612, 33412
AURORA.....	46014
AUVICO.....	46513, 57014
AVENTURA.....	88518
AVERA.....	68515
AVOL.....	87217, 89115
AXESS.....	41811
AXION.....	84315
BANG & OLUFSEN.....	24011
BELL & HOWELL.....	26618, 65312, 98215
BENO.....	87813, 95719, 19219, 80014
BLUE SKY.....	98314, 95017
BOE.....	89013, 19819
BOLVA.....	72015
BROCKWOOD.....	53411
BROKSONIC.....	81017, 65813, 57812, 75614, 55711, 54411
CCF.....	95017
CELERA.....	86718, 42113
CENTRICOS.....	82614
CETOMER.....	83314, 40412
CETRONIC.....	78613
CHANGHONG.....	01618, 72117
CHARTER COMMUNICATIONS.....	80415
CHIMEI.....	24912
CIELO.....	30812
CINERAL.....	63511, 95017
CITIZEN.....	58412, 60112, 93115, 78613, 79513, 63511
CLASSIC.....	46311, 04616, 78613
CLP CLASSIC.....	43411, 79914
COBY.....	13011, 77617, 96315, 52411, 52211, 61611, 77912
COLORTYME.....	33719
COMWAVE.....	32611
CONTEC.....	54312, 56511, 78613, 79513
CONTEX.....	20011
CORNEA.....	66712
CRAIG.....	19311, 24912, 23211, 78613, 79513
CROSLLEY.....	19711, 56011, 79914
CROWN.....	78613, 79513
CRYSTAL.....	72117
CTX.....	55411
CURTIS.....	11711, 47913, 68515, 79016, 80517, 64615, 20011
CURTIS INTERNATIONAL.....	07819, 47913, 68515,
CURTIS MATHES.....	79016, 80517, 91118, 90614, 17411, 58012,
DAEWOO.....	58412, 26618, 98215, 66411
CYBERVISION.....	95017
DAYTRON.....	74412, 42211, 84014, 78613,
DELL.....	68912, 63511, 33411, 85817, 90214
DÉVANT.....	43411
DEVANT.....	40211, 61211, 65411, 92815, 95017
DIAMOND VISION.....	94818, 27911, 05319
DIGIHOMÉ.....	59612, 86115, 54911, 57111
DIGIMATE.....	71415, 37819
DIGISTAR.....	63111
DIGITAL.....	42214, 71014, 65411, 78112
DIGITOR.....	83618
DISNEY.....	33113
DISTAR.....	81017
DSE.....	84218
DUKANE.....	22612
DUKANE.....	37219, 67412

DURABRAND.....	39213, 88518, 86718, 81017, 55514, 93115
DYNASTY.....	78613
DYNEX.....	12219, 49412, 39213, 45013, 82717,
.....	49813, 61215, 27311, 27711, 06919,
.....	28511, 28911, 39512, 89713, 79914, 88518
ELECTRO.....	54312, 56111
ELECTRON.....	80517
ELEKTA.....	83618
ELEKTRA.....	52814, 65312
ELEMENT.....	01815, 70017, 81918, 45112,
.....	72015, 34211, 79517, 24912, 34611
ELEMENT (ROKU TV).....	44211
EMERSON.....	29311, 36412, 48111, 82615, 88518, 46911,
.....	71714, 75614, 40411, 26618, 54711, 79513, 85913, 99714
ENVISION.....	40413, 31612, 33412
EQD.....	31612, 33412
ESA.....	88518, 25011, 93115
FAVI.....	11711
FISHER.....	26618, 72112, 66011
FLUID.....	70013
FUJICOM.....	76615
FUJITSU.....	54711, 74012
FUNAI.....	88518, 29311, 25011, 48111, 40411, 54711
FURRON.....	47414, 27911
FUTURETEC.....	78613, 79513
GATEWAY.....	20111, 59912
GE (GENERAL ELECTRIC).....	50115, 14951, 55514,
.....	42113, 87215, 73814, 90015, 00615
GENERAL INSTRUMENT.....	39019
GFM.....	88518, 29311, 03419, 25011
GIBRALTER.....	74916, 53511, 53911
GLOBALSTAR.....	49011
GOLDI.....	89013
GOLDSTAR.....	55514, 40411, 33411
GPX.....	24611, 23611, 46911
GRADIENTE.....	43411, 81214, 92114, 09215, 65311
GRUNDIG.....	37911
GUESTVISION.....	53311
GVISION.....	88113
HAIER.....	56013, 12511, 60914, 11711,
.....	55514, 43912, 54513, 77612
HAIER (ROKU TV).....	44211
HALLMARK.....	55514
HANNSPREE.....	15811, 26812
HAUPPAUGE.....	65911
HAVERMY.....	46511, 59912
NEXUS.....	36412, 82717
NEXTECH.....	62313, 62912
NIKAI.....	84218
NIKKELI.....	44211, 79513
NIKKO.....	55514, 63511
NIKO.....	47919
NOBEL.....	80313
NORCENT.....	40413, 38812
NTC.....	63511
NUVISION.....	02315
OBONI.....	17711, 94219, 85818
ÖLEVIA.....	80118, 17211, 85114
ONCOMMAND.....	53311, 65711
ONN.....	57513, 43612, 32011, 00717
ONN (ROKU TV).....	44211
ONWA.....	78613, 79513
OPTIMUS.....	64812, 39011
OPTOMA.....	45013, 69613, 82615, 61312
OPTONICA.....	47811, 55411
ORION.....	21311, 81017, 53511, 53911
PALSONIC.....	73717
PANASONIC.....	39011, 39811, 51913, 60513, 79515
PANDA.....	18911, 18411
PARK.....	64716
PEERLESS.....	18918
PENNEY.....	55514
PHILCO.....	25011, 41212, 63214, 76813,
.....	92815, 01115, 33411, 52814
PHILIPS.....	62414, 17419, 33412, 06918, 73915, 84416,
.....	95017, 44211, 21319, 43911, 48111, 82615, 88518
PHILIPS (ROKU TV).....	44211
PHILIPS-MAGNAVOX.....	56011, 69411, 73915, 86815, 51011
PIONEER.....	69913, 53714, 73513, 53811
PIVA.....	86914
PIXEL.....	99119
PLANAR.....	40413, 75812
POLAROID.....	89013, 33211, 68515, 24912, 40114, 58414,
.....	42113, 20011, 65014, 94016,
.....	43319, 07015, 67211, 16611
PORTLAND.....	63511, 33411
PRECISION.....	64713
PRIMA.....	27311, 66213, 71014
PRINCETON GRAPHICS.....	59611, 55411
PRISM.....	01117
PROMAC.....	26711
PROSCAN.....	47414, 11711, 34211, 07819, 93218, 20011,
.....	35611, 07017, 01815, 79712, 69416
PROTON.....	32818, 63111
PROTRON.....	24912
PROVIEW.....	24912

LENSON.....	74916, 53511, 53911
LETV.....	56614, 67115
LG.....	31311, 52412, 63913
LIQUIDVIDEO.....	84315, 17517
LODGENET.....	65312, 98215, 80714, 08415
LOEWE.....	56011
LOGIK.....	98215
LUCE.....	70514
LXI.....	55514, 58012, 53112, 40411, 26618, 60112, 98215, 56011
MAG.....	40114, 58414
MAGNASONIC.....	54711
MAGNAVOX.....	95017, 42812, 88518, 25011,
.....	42513, 48111, 82615, 51011, 63011
MAGNAVOX (ROKU TV).....	44211
MAJESTIC.....	98215
MARANTZ.....	33412, 53811, 56011
MASTER-G.....	01115
MATSUSHITA.....	39011
MAXENT.....	27117, 59912
MEDION.....	95515, 28118, 69112
MEGATRON.....	55514, 37219
MEI.....	54312
MELODY.....	36711
MEMOREX.....	20212, 55514, 53014, 12219, 74414, 85915,
.....	65813, 57812, 26618, 98215, 54711
MGA.....	55514, 54711, 75413, 56511, 67012, 33411
MI.....	21012
MIDLAND.....	74916, 87215, 58012, 53112,
.....	98215, 53511, 53911, 64511
MINOKA.....	36913
MINTEK.....	60916
MINUTZ.....	90015
MISAKAI.....	93115
MITSUBISHI.....	21711, 33411, 70215, 36311, 78112, 97415, 50912
MITSUI.....	21711, 70215, 36311, 78112, 19311, 17711, 29312,
.....	30813, 41314, 52215, 18311, 18711, 89713
MONIVISION.....	48011
MONTGOMERY WARD.....	65312, 98215
MOTEVA.....	26618, 92114
MOTOROLA.....	63712
MTC.....	54312, 58412, 60112, 33411
MYRON & DAVIS.....	91615
NAD.....	55514, 60112, 64911
NAXA.....	82318, 11711, 25811, 29419, 41011
NEC.....	29811, 31912, 47811, 53811, 33411
NET TV.....	46511, 59912
NEXUS.....	36412, 82717
NEXTECH.....	62313, 62912
NIKAI.....	84218
NIKKELI.....	44211, 79513
NIKKO.....	55514, 63511
NIKO.....	47919
NOBEL.....	80313
NORCENT.....	40413, 38812
NTC.....	63511
NUVISION.....	02315
OBONI.....	17711, 94219, 85818
ÖLEVIA.....	80118, 17211, 85114
ONCOMMAND.....	53311, 65711
ONN.....	57513, 43612, 32011, 00717
ONN (ROKU TV).....	44211
ONWA.....	78613, 79513
OPTIMUS.....	64812, 39011
OPTOMA.....	45013, 69613, 82615, 61312
OPTONICA.....	47811, 55411
ORION.....	21311, 81017, 53511, 53911
PALSONIC.....	73717
PANASONIC.....	39011, 39811, 51913, 60513, 79515
PANDA.....	18911, 18411
PARK.....	64716
PEERLESS.....	18918
PENNEY.....	55514
PHILCO.....	25011, 41212, 63214, 76813,
.....	92815, 01115, 33411, 52814
PHILIPS.....	62414, 17419, 33412, 06918, 73915, 84416,
.....	95017, 44211, 21319, 43911, 48111, 82615, 88518
PHILIPS (ROKU TV).....	44211
PHILIPS-MAGNAVOX.....	56011, 69411, 73915, 86815, 51011
PIONEER.....	69913, 53714, 73513, 53811
PIVA.....	86914
PIXEL.....	99119
PLANAR.....	40413, 75812
POLAROID.....	89013, 33211, 68515, 24912, 40114, 58414,
.....	42113, 20011, 65014, 94016,
.....	43319, 07015, 67211, 16611
PORTLAND.....	63511, 33411
PRECISION.....	64713
PRIMA.....	27311, 66213, 71014
PRINCETON GRAPHICS.....	59611, 55411
PRISM.....	01117
PROMAC.....	26711
PROSCAN.....	47414, 11711, 34211, 07819, 93218, 20011,
.....	35611, 07017, 01815, 79712, 69416
PROTON.....	32818, 63111
PROTRON.....	24912
PROVIEW.....	24912

PULSAR.....	74916, 53511, 53911
PYLE.....	68016
PYLE HOME.....	41811
QFX.....	48111
QUASAR.....	87215, 64812, 56011, 51913, 39011
RADIO SHACK.....	55514, 47811, 40411, 26618, 98215,
.....	54311, 56511, 79513, 00615
RCA.....	66114, 44712, 54113, 11711, 58915, 69416, 36412,
.....	04719, 26411, 22511, 33012, 44613, 55213, 65714,
.....	43912, 61513, 67013, 90214, 79712, 32111
RCA (ROKU TV).....	44211
REALISTIC.....	55514, 57512, 47811, 40411, 26618,
.....	98215, 78613, 79513, 79515
REVOLUTION HD.....	93819
RIVIERA.....	90614, 50613
ROKU TV.....	44211
ROWA.....	53815
RUNCO.....	74916, 53511, 53911, 53811
SAMPO.....	59912
SAMSUNG.....	21818, 97817, 77114, 79113, 16616, 36218, 66611
SAMTRON.....	58412
SANSUI.....	39213, 20011, 88518, 57812, 54411
SANYO.....	33711, 03818, 10811, 98718, 77715, 88513, 99014
SANYO (ROKU TV).....	44211
SCPTRE.....	37313, 19711, 65815, 20611, 30211, 83515, 05115
SCOTCH.....	55514, 54711, 75413, 56511, 67012, 33411
SCOTT.....	55514, 54711, 78613, 79513, 94215
SEARS.....	55514, 57812, 58412, 48111, 82615, 59211, 60112,
.....	93115, 98215, 54711, 56011, 68612, 72112
SEKI.....	64814, 01815, 79517, 55514, 96416, 11218, 22719
SELECTRON.....	74313, 85814, 78112
SEMP.....	70712
SÉURA.....	13019, 05517
SHARP.....	35611, 31713, 91517, 02118, 13019, 37311, 50912
SHARP (ROKU TV).....	55712, 13019
SHENG-CHIA.....	22511
SIGMAC.....	02019
SIGNATURE.....	98215
SIGNET.....	96715, 83414, 50911
SILO DIGITAL.....	20611
SIMPLY.....	76716
SIRAGON.....	26211
SKYVUE.....	37712
SKYWORTH.....	59315, 14319, 62415, 56112, 67211
SOAIY.....	89117
SOLE.....	93819
SONIC.....	54312
SONY.....	31912, 89616, 41112
SOULACA.....	16118
SOUNDESIGN.....	55514, 54711, 78613, 79513
SOVA.....	81213, 85613
SOYO.....	69613
SPECTRA.....	54911
SPECTRAVISION.....	48814
SPECTRONIQ.....	41313
SPELER.....	88518, 93115
SQUAREVIEW.....	50913
STAR SAT.....	79513
STARLITE.....	10818
SUMEC.....	19711, 65815, 92918, 80118, 20611
SUNBRITETV.....	84218
SUPER GENERAL.....	48111, 82615
SUPERSCAN.....	48111, 82615
SUPERSONIC.....	25811, 41811, 01117, 88715, 44711, 46911
SUPRA.....	72117, 43411, 78913
SVA.....	25011
SYLVANIA.....	9311, 25011, 48111, 40411, 88518, 81017,
.....	75315, 63614, 74115, 82615, 56011
SYMPHONIC.....	88518, 48111, 82615, 40411, 93115, 79513
SYNTAX.....	64716

Video - DVD / Vidéo - DVD

ACESONIC.....	43251
AIWA.....	35552, 23051, 26151, 68353, 81955
ALLEGRO.....	59252
AMES.....	73251
AMW.....	28251, 66255
ANABA.....	35351
APEX.....	77856, 19759, 53253, 51853, 45052, 69654, 42151
ASPIRE.....	59353
ASTAR.....	79154
A-TREND.....	33051
ATVIO.....	70759
AUDIOVOX.....	46552, 70354
AVORCENT.....	21651
AXION.....	46552
B & K.....	20551
BEL CANTO DESIGN.....	86658
BLAUPUNKT.....	53253, 86055
BLUE SKY.....	34452, 43651
BLU-RAY.....	45851, 44651, 66553, 46451, 82555, 48551, 48951
BOSE.....	45452, 51851, 51351
BOSS.....	35951
BOSTON ACOUSTICS.....	65053
BROKSONIC.....	23851, 55153, 68253
CALIFORNIA AUDIO LABS.....	19651
CAVS.....	89055
CENTRIOS.....	46552, 79455, 59253, 38451, 50853, 94357, 43552, 08457, 27758
CETOMER.....	68455
CHANG HONG.....	23151
CINEVISION.....	83254
CITECH.....	09458
CITIZEN.....	09458
CLASSIC.....	65155, 73255, 32951
COBY.....	33553, 11051, 77557, 88158, 11651, 22952, 48154
CONCEPT.....	53253, 86055
CRITERION.....	33352
CURTIS INTERNATIONAL.....	41253, 52154, 75356
CURTIS MATHES.....	30753
CYBERHOME.....	13851, 86957, 33051, 50351
CYBERVISION.....	47451
CYTRON.....	85757, 55454
DAEWOO.....	57954, 64154, 39351, 46852, 05756
DENON.....	37253, 31451, 46451
DENZEL.....	22951
DESAY.....	64555
DIAMOND VISION.....	27251, 88357, 64953
DIGIX.....	23551
DISNEY.....	92858, 15458
DRIVE.....	80755
DUAL.....	85757, 24951, 50654, 28451, 22951, 54252
DURABRAND.....	85757, 50852, 77754, 79154, 08457, 83254
DVD 2000.....	52855
DYNEX.....	21251, 51655, 63554, 41351, 06657
EIGERVISION.....	69853
ELEMENT.....	40751
ELTA.....	46453, 26151
EMERSON.....	26051, 27651, 42453, 39951, 71954, 15458, 53052, 50654
ESA.....	71954, 15458, 53052, 50654
ESCIENT.....	44151
FARENHEIT.....	39451
FISHER.....	49851, 50751
FUNAI.....	26051, 61855, 27651, 71954, 15458, 53052
GE (GENERAL ELECTRIC).....	14951, 53253, 86055
GO VIDEO.....	43053, 59755, 68455, 37652, 50254, 61155, 40253, 73255, 35551, 46852, 33151, 60453, 82455
GOLDSTAR.....	83254
GPX.....	25951, 25451, 36352, 47853, 58354, 34052
GRADIENTE.....	34452, 81255, 29256
GREENHILL.....	53253, 86055
HAAZ.....	39751, 34851
HAIER.....	37952, 20559
HARMAN/KARDON.....	51854
HD-DVD.....	45851, 67953, 44651, 82555, 48551, 48951
HELIOS.....	16551, 85556
HELLO KITTY.....	40054, 29252, 85757
HITACHI.....	82258, 26051, 61155, 40353, 22951, 20951, 82455
HUMAX.....	44652
ILO.....	97458, 76555, 68353
INITIAL.....	53253, 76555, 78554, 86055, 97556
INSIGNIA.....	59755, 60655, 55454, 46552, 76555, 41052, 80355, 57752, 71954, 04957, 73754, 83254
INTEGRA.....	81858, 15751, 67554
IRRADIO.....	30752
ISYMPHONY.....	38953, 49551
JBL.....	51854
JVC.....	32152, 97259, 19251, 20152, 31053, 39553, 35852, 56554, 73256, 52352, 49951, 38659, 94855
JWIN.....	59754, 19759, 36251, 87155
KAWASAKI.....	48553, 08457
KENWOOD.....	19651, 29251, 31552, 31451
KISS.....	22951
KLH.....	49753, 38152, 53253, 86055
KONKA.....	60655, 31251, 62354, 56653, 55553
KOSS.....	34452, 55454
KXD.....	24851
LASONIC.....	88357, 39751, 56452

LENOXX.....	26151, 57453, 79154
LG.....	59755, 18858, 50552, 61453, 61551, 83254, 58753, 88655
LIQUIDVIDEO.....	46552
LITEON.....	44853, 97458, 33151, 33651, 61354
MAGNAVOX.....	16257, 26752, 35852, 26651, 61855, 27651, 97757, 08258, 40352, 34551, 69254, 71954, 94855
MARANTZ.....	35852, 26752, 66955, 34551, 66054, 94855, 83254
MAXENT.....	47152, 70155
MEDION.....	85757, 27251, 97458, 35951, 47152
MEMOREX.....	85757, 58354, 83856, 41451, 87855, 68253
MERIDIAN.....	94855
MICROSOFT.....	76654
MICROVISION.....	35951
MINTEK.....	53253, 86055
MITSUBISHI.....	52855, 18251, 72954, 86055
MUSTEK.....	73255
MYRON & DAVIS.....	77655
NAD.....	29152, 13951, 35453, 46954, 30053, 41654, 52155, 83254, 47252, 79854
NAKAMICHI.....	78055
NEC.....	61551
NESA.....	53253, 77655, 86055
NEXSTECH.....	23551, 45653, 59054, 49053, 50654, 55454, 77856, 59253, 71755, 61454, 76455, 98957, 42151, 08457, 27758, 05756
NONCENT.....	21651, 39752, 33651
ORNKYO.....	24852, 81858, 38252, 67351, 41951, 41751, 19058, 94855
ONN.....	25351, 25751, 24551
OPTIMUS.....	82258, 44051
ORION.....	68253
ORITRON.....	34452, 94357, 12451, 10951
PACIFIC.....	85757
PANASONIC.....	16151, 44054, 19651, 92359, 50055, 28952, 18651, 40353, 62355, 93356
PHILCO.....	58352, 34353, 45854, 12251, 23752, 34253, 45154, 56755, 67256, 43454, 54955, 10451, 21352, 43354, 54255, 65856, 76357
PHILIPS.....	09259, 29751, 15251, 38653, 03359, 35852, 48153, 27651, 97757, 40352, 35851, 34551, 74354, 83455, 45551, 54152, 71954, 15458, 94855
PHILIPS-MAGNAVOX.....	26752, 35852, 66955, 94855
PIONEER.....	86658, 82258, 15451, 53954, 48752, 49351, 45151, 55652, 48551
PIVA.....	60154
POLAROID.....	76656, 87157, 67055, 62755, 77856, 56953, 42151, 32853
POLK AUDIO.....	26752, 13551, 35852, 66955, 34551, 94855
PORTLAND.....	26151, 05756
POWER ACOUSTIK.....	47951
PROLINE.....	16851, 34452
PROSCAN.....	31751
PROTRON.....	21651
PYLE.....	27452, 27959
RADIO SHACK.....	64455, 06858, 70855, 08457, 48553, 75157, 16051, 14951, 58354, 34452, 31751, 06858, 70855, 08457
REGENT.....	57453
REOC.....	39751
RIO.....	83254
RJ TECHNOLOGY.....	82256, 56052
ROSEN.....	17359, 89254
ROTEL.....	32152
SABA.....	64455
SAMSUNG.....	14451, 25352, 17651, 69255, 37652, 13959, 66754, 36651, 37451, 96457, 18559, 29359, 67653, 70454, 82455, 64653, 95455
SANSUI.....	23851, 68253
SANYO.....	24351, 58053, 52653, 08457, 50751, 16257
SEARS.....	27651, 68253, 71954
SEG.....	22951
SELECTION.....	72955, 49352, 72255, 32551, 65954, 87356, 30151, 66153
SEMP.....	55454
SENSORY SCIENCE.....	33151
SHARP.....	17151, 28652, 39153, 49554, 40151, 39959
SHERWOOD.....	45953, 95156
SHINCO.....	53253, 86055
SHINSONIC.....	53253, 86055
SICHLER-PEARL.....	53253, 86055
SONIC BLUE.....	40253
SONY.....	64656, 63755, 55952, 42654, 53155, 65753, 42151, 62153, 61151
SOUNDSTORM.....	27452, 35951
SOVA.....	91256
SPECTRONIQ.....	17051
SUNGALE.....	51154, 71355
SUPERSCAN.....	27651, 71954
SUPERSONIC.....	54654, 34052, 34353, 56355
SV2000.....	27651, 71954
SV4.....	55354
SYLVANIA.....	26051, 27651, 34151, 58053, 63853, 71954, 15458, 53052, 75554, 84655, 16257
SYMPHONIC.....	26051, 61855, 27651, 42453, 34151, 71954, 15458, 53052, 16257

TASCAM.....	13351, 32152
TCL.....	85255
TEAC.....	82258, 08457
TECHNICS.....	31451
TECHWOOD.....	35852, 44952, 47252, 54453, 42551
TERAPIN.....	60854
TEVION.....	85757, 28451, 55454, 33352, 75755, 39751, 34851
THETA DIGITAL.....	82258
TIVO.....	53954, 44652
TOSAKI.....	85757
TOSHIBA.....	29451, 26752, 25352, 36853, 47354, 58255, 14351, 14751, 91959, 72753, 40754, 23151, 37251, 30551, 07058, 46251, 68253, 94855
TREDEX.....	35951
TRUTECH.....	46852, 03357, 50351
UNITED.....	08457
URBAN CONCEPTS.....	29451
VENTURER.....	27052, 76254, 88457
VIOS.....	96258
VIZIO.....	74055, 51652, 51551, 51951, 62552, 73453, 74954
WESTINGHOUSE.....	61151
WHARFEDALE.....	34051
WHITE-WESTINGHOUSE.....	26051, 15458
XBOX.....	14951, 57455, 17558, 28159
XENIUS.....	55454
YAMAHA.....	26752, 35852, 66955, 08258, 31451, 42752, 40352, 45051, 77054
YAMAKAWA.....	41254, 22951, 22451, 38951
ZENITH.....	98658, 04957, 61551, 94855, 83254
ZUTEST.....	02959

Video - Blu Ray / Vidéo - Blu Ray

ALLEGRO.....	56951
ATVIO.....	76053, 87654
BLACK WEB.....	79453
BUSH.....	99655
CINEVISION.....	62852
DAEWOO.....	54251, 54651
DENON.....	53251, 90255, 84153
DISNEY.....	56451
DYNEX.....	55151, 61252
FUNAI.....	64752
HITACHI.....	40352, 66054, 95855
HP(HEWLETT PACKARD).....	29558
HUMAX.....	83246
INSIGNIA.....	59551, 66652, 02356, 69052
JBL.....	51854
JVC.....	81584
KENWOOD.....	66952, 77533
LG.....	53451, 62852, 58151, 52151
MAGNAVOX.....	71653, 64752, 25058
MAJESTIC.....	01856
MARANTZ.....	57551, 88054, 65252, 76753
MEMOREX.....	82554, 50653
MITSUBISHI.....	16061
CONTEC.....	74545
COOLSAT.....	62342, 93445
COX.....	76143, 43144, 25441, 64245
DELITASAT.....	62845
DIGITAL STREAM.....	99741
DIGIWAVE.....	25741
DIRECTV.....	54141, 56443, 44442, 62145, 75145, 71845, 51042, 62643
DIRECTV DRE.....	42142
DISH NETWORK.....	64945, 78445, 33141, 66544, 67944, 53444, 45842, 60244
DISHPRO.....	64945, 78445, 56542, 40141, 28848
DMT.....	22241
DRAKE.....	74144, 68043
DREAMBOX.....	59341, 60842
DX ANTENNA.....	23949
EASTERN.....	85346
EASTLINK.....	65642
ECHOSPHERE.....	34341
ECHOSTAR.....	51244, 44343, 55844, 66345, 33742, 64945, 34341
EMTEC.....	88544, 99045
ENTONE.....	63145
ENVISION.....	24441
EVERQUEST.....	76945
EVOLUTION.....	54345, 20441, 64245, 35941
EXPRESSVU.....	64945, 78445, 61843
FORTEC STAR.....	52443, 49741, 55042, 77544
FRONTIER.....	76143, 65642
FUJITSU.....	46241
GARRARD.....	88045
GC ELECTRONICS.....	50342
GE (GENERAL ELECTRIC).....	49441, 45541, 57142, 81745, 42941
GEMINI.....	87846, 63944, 72344
GENERAL INSTRUMENT.....	62145, 56842, 65143, 87645, 46641
GENERAL INSTRUMENT (GI).....	29241
GEOSTAPRO.....	91848
GLOBALSAT.....	33041
GLOBECASAT.....	65444, 48941
GO VIDEO.....	71443
GOI.....	64945
GOLDSTAR.....	43641
GOODMIND.....	82945
HAMLIN.....	81745
HFC.....	39242
HILTON.....	77045
HITACHI.....	62145, 56842, 43641, 54942
HNS.....	62145
HOMIEZUS.....	34541
HOMECASAT.....	17749, 34141
HOMEWORX.....	96648, 60542
HTS.....	64945
HUAWEI.....	34541
HUGHES NETWORK SYSTEMS.....	48643, 54141
HUMAX.....	40541, 54141
ILICO.....	43144
ILO.....	59342
INFOCUS.....	31342
INSIGHT.....	25441, 81844
INSIGNIA.....	52644
IVEW.....	50343
JASCO.....	88045
JERROLD.....	66643, 32941, 49941, 43641, 47441
JVC.....	06945
JYNXBOX.....	77246
KAON.....	75846
KENWOOD.....	48441
KNOLOGY.....	39242, 25441, 58144, 43144
KOOLCONNECT.....	54441
KLWORD.....	72813
LASONIC.....	37442
LAYER3.....	98645
LG.....	62145, 66042
LITEON.....	59342
LUXOR.....	66447
MACOM.....	43041
SUPER GUIDE.....	61144, 83246, 65642
MAGNAVOX.....	42843, 46342
MANHATTAN.....	43342, 44442, 43144, 80145
MEDIA.COM.....	25241
MEDIAONE.....	62845, 25441, 34541, 65642
MEDIAONIC.....	39242, 29241
MEDION.....	86347
MEGACABLE.....	59342
MEMOREX.....	30941
METROCAST.....	39242
METROCAST CABLEVISION.....	34541
MICROGEM.....	59145
MICROYAR.....	37042
MIDCONTINENT COMMUNICATIONS.....	34541
MITSUBISHI.....	87744
MOTOROLA.....	28241, 48943, 40743, 95747, 34541, 48142, 44141, 39242
MOVIE TIME.....	07448
MOVISTAR.....	44042
MOXI.....	47942, 27141, 61645
MXQ.....	38241
MYRIO.....	26141
NAGRAVISION.....	26041
NEOSAT.....	64443
NEOTION.....	24341
NET.....	60045, 26041, 73544, 51941
NET DIGITAL.....	60045
NETGEM.....	37533
NETLEVEL.....	29641
NOVAPLEX.....	98347, 69243
NOVUS.....	46843, 65642
NOW TV.....	97346
NSC.....	07448
OAK.....	27641
OI.....	37641
OMEGA.....	24941
OMEGASAT.....	24941
OPENBOX.....	68245, 39142
OPTIMUM.....	43144, 25441, 33541
ORASAT.....	36742
OXFORD.....	24741
PACE.....	43144, 76143, 25441, 26041, 95747, 65642, 39242, 50744, 34541
PANASONIC.....	74445, 96947, 34541, 85745, 48441, 82245
PANSAT.....	20349
PARAGON.....	30941</