

## Code Lists

### Listes de Codes

### Lista de Códigos

#### TV / Téléviseur

ABEX.....	96416, 72723
ADC.....	43911, 46911
ADVENT.....	69416, 83515, 76314, 62213
AFFINITY.....	56415
AIKO.....	65312
AIWA.....	12618
AKAI.....	94818, 18311, 55514, 85818, 57515
ALLERON.....	80415
AMTRON.....	71014
AMW.....	05517, 5012
ANAM NATIONAL.....	69913, 48011, 71014, 42611, 28118
AOC.....	27411, 27911, 80517, 48213, 45013, 78115, 20011, 23211
AOC (ROKU TV).....	61514
APEX.....	20212, 29312, 56614, 76615, 41112, 18918, 56112, 78614, 00717
APEX DIGITAL.....	00717
ARIO.....	32913
ATVIO.....	90919, 12911, 82717, 91517
ATVIO (ROKU TV).....	61514
AUDIOVOX.....	71014, 88114, 99715
AURIA.....	45013, 23211
AVENTURA.....	55615
AVERA.....	41314, 38111
AVOL.....	41314, 38111
AXESS.....	36411
AXION.....	01117
BANG & OLUFSEN.....	65815
BELL & HOWELL.....	66213, 46911, 79914
BENQ.....	33719, 35513, 46811, 53212
BLUE SKY.....	27311
BOE.....	56011, 27911
BROVA.....	46912
BROCKWOOD.....	21012, 65714, 30611, 61513, 87215, 46511
BROKSONIC.....	21012, 65714, 30611, 61513, 87215, 46511
CC.....	27311
CELERA.....	31713, 56614
CETOMER.....	84715, 28911
CETRONIC.....	69913
CHANGHONG.....	66015, 25412
CHIMEI.....	92419
CINERAL.....	65312, 27311
CITIZEN.....	85915, 88715, 44711, 69913, 71014, 65312
CLASSIC.....	69913
CLP.....	32011
CLP CLASSIC.....	43612, 74815
COBY.....	81918, 44714, 86115, 62313, 73814, 51611, 97415
COLORTYME.....	43911
CONTEC.....	54113, 47811, 69913, 71014
CONTEX.....	04719
CORNEA.....	54312
CRAIG.....	42214, 92419, 09619, 69913, 71014
CROSLLEY.....	53815, 60113, 74815
CROWN.....	69913, 71014
CRYSTAL.....	25412
CTX.....	43411
CURTIS.....	66116, 21412, 32913, 32212, 43713, 82717, 04719
CURTIS INTERNATIONAL.....	56415, 21412, 32913, 32212, 43713
CURTIS MATHES.....	56811, 46014, 63614, 85915, 66213, 79914
CYBERVISION.....	27311
DAEWOO.....	31919, 27019, 44211, 69913, 60513, 65312, 20011, 34413, 56511
DAYTRON.....	43612
DELL.....	23219, 39019, 11717, 42211, 27311
DEVANT.....	29311, 58414, 30812
DIAMOND VISION.....	72014, 24919
DIGHOME.....	40412, 51913
DIGIMATE.....	54411
DIGISTAR.....	99119, 83515, 11717, 90015
DIGITAL.....	36913
DISNEY.....	21012
DISTAR.....	24912
DUKANE.....	77114, 82615
DURABRAND.....	83618, 55615, 31713, 21012, 78616, 44711
DYNASTY.....	69913
DYNEX.....	22011, 57513, 83618, 21711, 63315, 81017, 03419, 25011, 25811, 36412, 47913, 68515, 79016, 56111, 74815, 55615
ELECTRO.....	54113, 47011
ELECTRON.....	43713
ELEKTA.....	36913
ELEKTRA.....	12511, 46911
ELEMENT.....	67012, 71817, 82318, 44913, 46912, 22811, 47414, 92419, 33412
ELEMENT (ROKU TV).....	61514

EMERSON.....	12311, 10811, 07017, 41011, 55615, 41212, 29419, 61513, 12618, 66213, 80415, 71014, 53511, 75413
ENVISION.....	80517, 45013, 23211
EOD.....	45013, 23211
ESA.....	55615, 54015, 44711
FAVI.....	66116
FIRE TV.....	71817
FISHER.....	66213, 51011
FLUID.....	53112
FUJICOM.....	12219
FUJITSU.....	80415, 76813
FUNAI.....	55615, 12311, 54015, 07017, 12618, 80415
FURRION.....	48814, 58414
FUTURETEC.....	69913, 71014
GE (GENERAL ELECTRIC).....	13011, 14951, 78616, 56614, 32611, 90616, 59612, 86914
GENERAL INSTRUMENT.....	00717
GFM.....	55615, 12311, 43514, 54015
GIBRALTER.....	23512, 46311, 57812
GOLDI.....	56011
GOLDSTAR.....	78616, 12618, 20011
GPX.....	54214, 21311, 41212
GRADIENTE.....	43612, 86815, 59211, 55411, 55211
GUESTVISION.....	70514
GVISION.....	64512
HAIER.....	20111, 38013, 39811, 66116, 78616, 34611, 45112, 53911
HAIER (ROKU TV).....	61514
HALLMARK.....	78616
HANNSPREE.....	19711, 37313
HAUPPAUGE.....	93115
HAVERMUY.....	57014
HELLO KITTY.....	64812
HISENSE.....	39812, 61514, 31612, 42113, 39011
HISENSE (ROKU TV).....	61514, 72015
HITACHI.....	70017, 23611, 13019, 51913, 50011, 36711
HITACHI (ROKU TV).....	61514
HKC.....	48814
HP (HEWLETT PACKARD).....	91019, 62912
HYUNDAI.....	38011, 54711, 67412
IO.....	89115, 44711, 48111, 71714, 95216, 95515, 59611, 55615
INFINITY.....	22719, 60113
INFOCUS.....	76716, 17151
INITIAL.....	48111
INSIGNIA.....	68515, 22011, 57513, 47913, 36412, 40211, 64713, 56111, 79016, 21711, 74115, 41011, 73114
INSIGNIA (FIRE TV).....	71817
INSIGNIA (ROKU TV).....	22011, 61514
INTECO.....	23512, 46311, 57812
ISYMPHONY.....	66116
JBL.....	60113
JC PENNEY.....	32611, 85915, 88715, 79914, 59612, 28118, 20011
PROVIEW.....	92419
JOCEL.....	78613
JVC.....	20611, 53714, 64615, 80016, 41811, 65813, 68413
JVC (ROKU TV).....	61514
KALLEY.....	67412
KAWASHO.....	47011
KDC.....	94219, 23812
KEC.....	69913
KLH.....	56614
KLOSS NOVABEAM.....	63214
KNOLL SYSTEMS(ZENITH).....	23512
KONIG.....	64512
KONKA.....	21711, 79113, 38011, 43711, 21319, 87314
KTV.....	54113, 69913, 71014
KURAZAI.....	46911
LASONIC.....	72014, 24919
LEGEND.....	32913, 83515
LENOVO.....	27112
LETV.....	41313, 52814
LG.....	38312, 47312, 58813
LIQUIDVIDEO.....	01117
LOGGENET.....	46911, 79914, 48611, 21818
LOWE.....	60113
LOGIK.....	79914
LXI.....	78616, 63614, 49011, 12618, 66213, 88715, 79914, 60113
MAG.....	78616, 74414, 12618, 66213
MAGNASCAN.....	79914, 48115
MAGNAVOX.....	27311, 49813, 55615, 54015, 26211, 07017, 41011, 22719, 54311
MAGNAVOX (ROKU TV).....	61514
MAJESTIC.....	79914
MARANTZ.....	23211, 69613, 60113
MASTER-G.....	67412
MATSUSHITA.....	06919
MAXENT.....	06016, 52412
MEDION.....	89115
MEGATRON.....	78616, 77114
MEI.....	54113
MELODY.....	84416
MEMOREX.....	77617, 78616, 37712, 22011, 66114, 77715, 65714, 30611, 66213, 79914, 80415
MGA.....	78616, 80415, 47511, 47811, 58412, 20011
MI.....	51715

MIDLAND.....	23512, 32611, 63614, 49011, 79914, 46311, 57812, 66712
MINUTZ.....	24912
MISAKAI.....	44711
MITSUBISHI.....	90919, 20011, 62414, 73915, 90015, 58012, 80415
MITSUI.....	90919, 62414, 73915, 90015, 42214, 16611, 56111
MONTGOMERY WARD.....	46911, 79914
MOTIVA.....	66213, 59211
MOTOROLA.....	84315
MTC.....	54113, 85915, 88715, 20011
NAD.....	78616, 88715, 77213
NAXA.....	97619, 66116, 10011, 14319, 36911
NEC.....	12811, 26411, 74414, 69613, 20011
NET TV.....	65014, 52412
NEXUS.....	10811, 63315
NIKAI.....	24912
NIKKO.....	69913
NOBEL.....	78616, 65312
NORCENT.....	80517, 60513
NTC.....	65312
ONBONI.....	16611, 57515
ÖLEVIA.....	58915, 61616, 40411
ONCOMMAND.....	70514
ONN.....	33012, 89616, 34211, 38511
ONN (ROKU TV).....	61514, 68612
ONWA.....	69913, 71014
OPTIMUS.....	81015, 06919
OPTOMA.....	64013
OPTONICA.....	74414, 43411
ORION.....	18711, 21012, 46311, 57812
PANASONIC.....	06919, 28511, 39512, 63913, 40413
PARK.....	10011
PENNEY.....	78616
PHILCO.....	54015, 67614, 99717, 57512, 42211, 67412, 20011, 12511
PHILIPS.....	50314, 27711, 23211, 61215, 27311, 61514, 07017, 41011, 55615
PHILIPS (ROKU TV).....	61514
PHILIPS-MAGNAVOX.....	60113, 15117, 61215, 16118, 22719
PIONEER.....	96416, 67115, 44411, 69613
PLANAR.....	80517, 54911
POLAROID.....	56011, 31912, 32913, 92419, 94219, 23812, 56614, 04719, 56013, 70215, 82614, 98215, 78613, 79517
PORTLAND.....	65312, 20011
PRIMA.....	25011, 38011, 83515
PRINCETON GRAPHICS.....	43411
PRISM.....	37911
PROSCAN.....	48814, 66116, 22811, 56415, 79513, 74916, 04719, 39812, 03818, 67012, 57111, 60916
PROTON.....	78616
PROTRON.....	71013, 54411
PROVIEW.....	92419
PULSAR.....	23512, 46311, 57812
PYLE.....	26812
PYLE HOME.....	26812
QFX.....	36411
QUASAR.....	32611, 81015, 60113, 39512, 06919
RADIO SHACK.....	78616, 74414, 12618, 66213, 79914, 47811, 71014, 88614
RCA.....	53313, 42513, 90117, 66116, 57011, 79513, 80714, 59315, 60916, 10811, 85817, 96318, 57014, 53014, 01618, 34611, 36711, 37311, 56511, 57111, 68014
RCA (ROKU TV).....	61514
REALISTIC.....	78616, 52713, 74414, 12618, 66213, 79914, 69913, 71014, 40413
REVOLUTION HD.....	19311
RIVIERA.....	56811, 35611
ROKU TV.....	61514, 72015, 28311, 22011
RUNCO.....	23512, 46311, 57812, 69613
SAMPO.....	52412
SAMSUNG.....	43311, 94818, 38811
SAMTRON.....	85915
SANSUI.....	83618, 04719, 55615, 30611, 69212, 46511
SANYO.....	75315, 86916, 96319, 52215, 64814, 53811, 53311
SANYO (ROKU TV).....	61514
SCEPTRE.....	64716, 53815, 30813, 93218, 68912, 11719, 69314, 84014
SCOTCH.....	78616
SCOTT.....	79914, 23812
SEALOC.....	80014
SEARS.....	78616, 30611, 85915, 07017, 41011, 88715, 44711, 79914, 80415, 60113, 51011
SEIKI.....	59114, 67012, 47414, 78616, 33711, 49012, 50613
SELECTRON.....	90015
SEMP.....	37219
SÉURA.....	28311
SHARP.....	39812, 88518, 62415, 28811, 91615, 28311, 79515, 36311
SHARP (ROKU TV).....	72015, 28311
SHENG-CHIA.....	57014
SIGNATURE.....	79914
SIL DIGITAL.....	93218
SKYWORTH.....	75217, 97817, 02019, 37811, 78613
SOLE.....	19311
SONIC.....	54113
SONY.....	26411, 44613, 33211

SOUNDESIGN.....	78616, 80415, 69913, 71014
SOYO.....	74115
SPECTRA.....	24912
SPECTRUM.....	70713
SQUAREVIEW.....	55615, 44711
STARLITE.....	71014
SUMEC.....	32111
SUNBRITETV.....	53815, 30813, 32613, 58915, 93218
SUPER GENERAL.....	24912
SUPERSCAN.....	07017, 41011
SUPERSONIC.....	10011, 36411, 37911, 49412, 50913, 41212
SUPRA.....	25412, 43612
SVA.....	54015
SYLVANIA.....	12311, 54015, 07017, 12618, 55615, 21012, 60715, 44712, 55213, 41011, 60113
SYMPHONIC.....	55615, 07017, 41011, 12618, 44711, 71014
SYNTAX.....	11711
TATUNG.....	34112, 89115, 46811
TCL.....	78913, 84416, 33012, 95017, 57011, 06918, 36711, 61514
TCL (ROKU TV).....	61514
TECHNICOLOR.....	01618
TECHNICS.....	32611, 69159
TECHWOOD.....	32611, 44411
TEKNIKA.....	63214, 85915, 88715, 79914, 80415, 69913, 65312, 20011, 40413
TELERENT.....	46911, 79914
TERA.....	43612
TEVION.....	89115
THOMSON.....	78913
TMK.....	60916
TNCI.....	23512
TOSHIBA.....	89514, 08318, 17419, 19819, 56013, 10511, 05319, 15919, 37511, 48812, 54513, 30611
TOSHIBA (FIRE TV).....	71817
TRUTECH.....	55615, 92419, 22218
TVA.....	02118
TVS.....	21012
UNIVERSAL.....	49611, 59612
UPSTAR.....	69915, 17749
VENTURER.....	11218, 93115
VESTEL.....	40412
VICTOR.....	65813
VIDEOCON.....	55711
VIDTECH.....	78616, 20011
VISIONSONIC.....	31811, 93819, 49614, 50115, 57611, 73717, 84218, 95719, 17211, 28712, 39213, 20114, 52412, 45013, 82615, 23311
VIORE.....	66116, 10011, 21412, 51712
VISION QUEST.....	92419
VIZIO.....	22111, 28911, 51914, 34112
WARD'S.....	23512, 78616, 74414, 79914, 80415, 59612, 60113, 20011
WAYCON.....	10511
WBOX.....	48512, 59413, 60914
WESTINGHOUSE.....	31311, 26411, 42812, 66116, 32913, 07819, 10781, 09989, 21581, 63085
WESTINGHOUSE (ROKU TV).....	61514
WHITE-WESTINGHOUSE.....	21012, 94016, 12618, 56511
WINDSOR.....	51912
WYSE.....	73717
XIAOMI.....	51715
XOCECO.....	79517
YAMAHA.....	20011, 44413
YAUFEY.....	35182
ZUTEST.....	36682

#### Projector / Proyector / Projecteur

3M.....	46284, 51985, 30483, 45584, 78487, 43784, 65186, 60985
AAXA.....	47084
ACER.....	45283, 14081, 21981, 32582, 32882, 29581
ADJ.....	21381
AEHR.....	35182
ASUS.....	12181
AVERMEDIA.....	36583
AVIO.....	46684



PLYE.....	27452, 27959
RADIO SHACK.....	64455, 06858, 70855, 08457, 48553
RCA.....	75157, 16051, 14951, 58354, 34452, 31751, 06858, 70855, 08457
REGENT.....	57453
REOC.....	39751
RIO.....	83254
RJ TECHNOLOGY.....	82256, 56052
ROSEN.....	17359, 54252
ROTEL.....	32152
SABA.....	44455
SAMSUNG.....	14451, 25352, 17651, 69255, 37652, 13959, 66754, 36651, 37451, 96457, 18559, 29359, 67653, 70454, 82455, 64653, 95455
SANSUI.....	23851, 68253
SANYO.....	24351, 58053, 52653, 08457, 50751, 16257
SEARS.....	71954
SEGS.....	22951
SEMP.....	72955, 49352, 72255, 32551, 65954, 87356, 30151, 66153
SEMPER.....	55454
SENSORY SCIENCE.....	33151
SHARP.....	17151, 28652, 39153, 49554, 40151, 39959
SHERWOOD.....	45953, 95156
SHINCO.....	53253, 86055
SHINSONIC.....	53253, 86055
SICHLER-PEARL.....	53253, 86055
SONIC BLUE.....	40253
SONY.....	64656, 63755, 55952, 42654, 53155, 65753, 42151, 62153, 61151
SOUNDSTORM.....	27452, 35951
SOVA.....	91256
SPECTRONIQ.....	71051
SUNGAL.....	51154, 71355
SUPERSCAN.....	27651, 71954
SUPERSONIC.....	54654, 34052, 34353, 56355
SV2000.....	27651, 71954
SVA.....	55354
SYLVANIA.....	26051, 27651, 34151, 58053, 63853, 71954, 17458, 53052, 75554, 84655, 16257
SYMPHONIC.....	26051, 61855, 27651, 42453, 34151, 71954, 15458, 53052, 53052, 16257
TASCAM.....	13351, 32152
TCL.....	82258, 85255
TEAC.....	82258, 08457
TECHNICS.....	31451
TECHWOOD.....	35852, 44952, 47252, 54453, 42551
TERAPIN.....	60854
TEVION.....	85757, 28451, 55454, 33352, 75755, 39751, 34851
THETA DIGITAL.....	82258
TIVO.....	53954, 44652
TOSAKI.....	85757
TOSHIBA.....	29451, 26752, 25352, 36853, 47354, 58255, 14351, 14751, 91959, 72753, 40754, 23151, 37251, 30551, 07058, 46251, 68253, 94854
TREDEX.....	46852, 03357, 50351
TRUTECH.....	08457
UNITED.....	29451
URBAN CONCEPTS.....	29451
VENTURER.....	27052, 76254, 08457
VIOS.....	96258
VIZIO.....	74055, 51652, 51551, 51951, 62552, 73453, 84954
WESTINGHOUSE.....	61151
WHARFEDALE.....	34051
WHITE-WESTINGHOUSE.....	26051, 15458
XBOX.....	14951, 57455, 17558, 28159
XENIUS.....	55454
YAMAHA.....	26752, 35852, 66955, 08258, 31451, 42752, 40352, 45051, 77054
YAMAKAWA.....	41254, 22951, 22451, 38951
ZENITH.....	98658, 04957, 61551, 94855, 83254
ZUTEST.....	02959

**Video - Blu Ray / Vidéo - Blu Ray**

ALLEGRO.....	56951
ATVIO.....	76053, 87654
BLACK WEB.....	79453
BUSH.....	99655
CINEVISION.....	62852
DAEWOO.....	54251, 54651
DENON.....	53251, 90255, 74153
DISNEY.....	56451
DYNEX.....	55151, 61252
FUNAI.....	64752
HITACHI.....	75253
HP(HEWLETT PACKARD).....	29558
HUMAX.....	83246
INSIGNIA.....	59551, 66652, 02356, 69052
JBL.....	51854
JVC.....	81554
KENWOOD.....	66952, 77553
LG.....	53451, 62852, 58151, 52151
MAGNAVOX.....	71653, 64752, 25058
MAJESTIC.....	01856
MARANTZ.....	57551, 88054, 65252, 76753
MEMOREX.....	82554, 70653
MITSUBISHI.....	16061
ONKYO.....	88551

ONN.....	68552
OPPO.....	86854, 97355, 83653, 85754
PANASONIC.....	59851, 57951, 58255
PHILCO.....	87254, 98855
PHILIPS.....	98155, 59151, 59055, 14457
PIONEER.....	55651, 96655
POLAROID.....	65152
POPCORN HOUR.....	89354
PROSCAN.....	14951
RCA.....	86154
SAMSUNG.....	94554, 60452, 55051, 67352, 78853, 12357, 30159, 72052
SANYO.....	64752
SHARP.....	97755, 24458, 52751
SHERWOOD.....	71953, 07156
SONY.....	05055, 60052, 75353
SYLVANIA.....	88754, 03556
TCL.....	36559
TOSHIBA.....	93055, 59051, 80954, 13957
VIORÉ.....	91555
VIZIO.....	77153, 08256, 63652
YAMAHA.....	89454, 18657
ZUTEST.....	91455

**Cable Set Top Box / Boîtier décodeur pour câble / Convertidor para Cable**

**Satellite Set Top Box / Boîtier décodeur pour satellite / Convertidor para Satélite**

ABC.....	01949, 32941, 66643, 43641
ACCESS HD.....	53344
ADD.....	81747
ADELPHIA.....	43144, 34841
ADTH.....	53542
HTS.....	76245
ALITICE.....	25441
AMERICAST.....	29241, 23341
AMINO.....	55643
AMPER.....	44243
ANTRONIX.....	41241, 50342
TASCAM.....	13351, 32152
TEAC.....	82258, 85255
TECHNICS.....	31451
TECHWOOD.....	35852, 44952, 47252, 54453, 42551
TERAPIN.....	60854
TEVION.....	85757, 28451, 55454, 33352, 75755, 39751, 34851
THETA DIGITAL.....	82258
TIVO.....	53954, 44652
TOSAKI.....	85757
TOSHIBA.....	29451, 26752, 25352, 36853, 47354, 58255, 14351, 14751, 91959, 72753, 40754, 23151, 37251, 30551, 07058, 46251, 68253, 94854
TREDEX.....	46852, 03357, 50351
TRUTECH.....	08457
UNITED.....	29451
URBAN CONCEPTS.....	29451
VENTURER.....	27052, 76254, 08457
VIOS.....	96258
VIZIO.....	74055, 51652, 51551, 51951, 62552, 73453, 84954
WESTINGHOUSE.....	61151
WHARFEDALE.....	34051
WHITE-WESTINGHOUSE.....	26051, 15458
XBOX.....	14951, 57455, 17558, 28159
XENIUS.....	55454
YAMAHA.....	26752, 35852, 66955, 08258, 31451, 42752, 40352, 45051, 77054
YAMAKAWA.....	41254, 22951, 22451, 38951
ZENITH.....	98658, 04957, 61551, 94855, 83254
ZUTEST.....	02959

EASTERN.....	85346
EASTLINK.....	65642
ECHOSPHERE.....	24741
ECHOSTAR.....	51244, 44343, 55844, 66345, 33742, 64945, 34341
EMTEC.....	88544, 99045
ENTONE.....	63145
ENVISION.....	02349
EVERQUEST.....	76945
EVOLUTION.....	54345, 20441, 64245, 35941
EXPRESSVU.....	64945, 78445, 61843
FORTEC STAR.....	52443, 49741, 55042, 77544
FRONTIER.....	76143, 65642
FUJITSU.....	46241
GARRARD.....	88045
GC ELECTRONICS.....	50342
GE (GENERAL ELECTRIC).....	49441, 45541, 57142, 81745, 42941
GENIUM.....	87846, 63944, 72344
GENERAL INSTRUMENT.....	62145, 56842, 65143, 87645, 46641
GENERAL INSTRUMENT (GI).....	29241
GEOSATPRO.....	91848
GLOBALSAT.....	33041
GLOBECAST.....	65444, 48941
GO VIDEO.....	71443
GOI.....	65642
GOLDSTAR.....	82945
GOODMIND.....	81745
HAMLIN.....	89445, 66643
HFC.....	39242
HILTON.....	77045
HITACHI.....	62145, 56842, 43641, 54942
HNS.....	62145
HOME2US.....	34541
HOMECAST.....	17749, 36141
HOMEWORX.....	49742
HTS.....	64945
HUAWEI.....	34541
HUGHES NETWORK SYSTEMS.....	48643, 54141
HUMAX.....	40541, 54141
ILLICO.....	43144
ILO.....	59342
INFOCUS.....	43641
INSIGHT.....	25441, 58144
INSIGNIA.....	52644
IVIEW.....	50343
JASCO.....	88045
JERROLD.....	66643, 32941, 49941, 43641, 47441
JVC.....	64945
JYNXBOX.....	77246
KAON.....	75846
KENWOOD.....	78944
KNOLOGY.....	39242, 25441, 58144, 43144
KOOLCONNECT.....	55643
STANDARD.....	49341
LAYERS.....	98645
LG.....	62145, 66042
LITEON.....	59342
LUXOR.....	06447
M2.....	76543, 87044, 64242
MACOM.....	43041
MAG.....	42843, 46342
MAGNAVOX.....	43342, 44442, 43141, 80145
MANHATTAN.....	25241
MEDIACOM.....	62845, 25441, 34541, 65642
MEDIAONE.....	39242, 29241
MEDIAONIC.....	86347
MEDION.....	59342
MEGACABLE.....	39242
MEMOREX.....	30941
METROCAST.....	39242
METROCAST CABLEVISION.....	34541
MICROGEM.....	59145
MICROYAL.....	37042
MIDCONTINENT COMMUNICATIONS.....	34541
MITSUBISHI.....	87744
MOTOROLA.....	28241, 48943, 40743, 95747, 34541, 48142, 44141, 39242
MOVIE TIME.....	07448
MOVISTAR.....	44042
MXI.....	47942, 27141, 87744, 62145
MXQ.....	38241
MYRIO.....	26141
NAGRAVISION.....	26041
NEOSAT.....	49441, 54642
NEOTION.....	24341
NET.....	60045, 26041, 73544, 51941
NET DIGITAL.....	60045
DIGIWAVE.....	25741
DIRECTV.....	54141, 56443, 44442, 62145, 75145, 71845, 51042, 62643
DIRECTV DRE.....	42142
DISH NETWORK.....	65942, 64945, 78445, 33141, 66544, 67944, 53444, 45842, 60244
DISHPRO.....	64945, 78445, 56542, 40141, 28848
DMT.....	22441
DRAKE.....	74144, 68043
DREAMBOX.....	59341, 60845
DX ANTENNA.....	23949

OPTIMUM.....	43144, 25441, 33541
ORASAT.....	36742
OXFORD.....	24741
PACE.....	43144, 76143, 25441, 26041, 95747, 65642, 39242, 50744, 34541
PANASONIC.....	74445, 96947, 34541, 85745, 48441, 82245
PANVISION.....	02349
PARAGON.....	30941
PHILCO.....	55144
PHILIPS.....	87744, 12641, 54745, 32441, 29749, 60843
PHILIPS-MAGNAVOX.....	44442, 67445, 54843, 43141, 80145
PHILO.....	27141
PINNACLE.....	19448, 59541, 59941
PIONEER.....	25441, 66943
POLAROID.....	55041
PRIME.....	59544
PRIMESTAR.....	43543
PROSCAN.....	81345, 86545
PULSAR.....	42941, 49441, 57142, 71344
QUASAR.....	30941
RADIO SHACK.....	67445, 54843, 76245
RCA.....	41043, 71444
RCN.....	65642
REALISTIC.....	52742, 50342, 95546
REGENCY.....	85346
REMBRANDT.....	43641
ROGERS.....	25441, 45443, 56944, 65642
RUNCO.....	30941
SAMSONIC.....	86445
SAMSUNG.....	43144, 32243, 58143, 55141, 54141
SANSONIC.....	71147
SASKTEL.....	34542
SCIENTIFIC ATLANTA.....	43144, 29241, 34541, 98347, 41542, 07747
SERVICE ELECTRIC.....	34541
SHARP.....	96648, 60542
SHAW.....	27141, 34541, 48142, 65642
SHAW DIRECT.....	77143, 54141
SIERRA II III.....	79244
SIGNAL.....	76945
SIGNATURE.....	43641
SKY.....	48643, 21742, 40043, 51644, 28549, 38642, 38942, 49543, 50044
SKY HD.....	48643, 54141
SKY NETWORK.....	28549, 73843, 84344, 95245, 51341
SKYBOX.....	68245
SKYMASTER.....	56845
SL MARX.....	76945
SONICVIEW.....	08648
SONY.....	71845, 65344, 83245, 54642, 79644, 04347, 55541, 77643
SPECTRUM.....	39242, 43144, 19249, 31241
SPRUCER.....	48441
STANDARD.....	49341
STAR CHOICE.....	29641, 43543, 84045
STAR SIGHT.....	18248, 70144
STAR TRACK.....	45841
STARCOM.....	16848, 66643
STARGATE.....	76945
STS.....	23949
SUDDEN LINK.....	17141, 39242, 25441, 34541, 61144, 83246, 65642
SUPER GUIDE.....	44841
SUREWEST.....	23841
SYLVANIA.....	43144, 23841
SYLVANIA.....	82944
TANDY.....	45341
TECHNICOLOR.....	62144, 34541
TELEFONICA.....	37042, 69744
TELEGENIC.....	72345
TELEVISION.....	76945
TELSTAT.....	51441
TELUS.....	35342
TEXSCAN.....	49341
THOMPSON.....	62144
THOMPSON.....	34541
TIME WARNER.....	43144, 25441, 41241
TIVAX.....	53344
TIVO.....	07249, 60644, 83246
TOSHIBA.....	65246, 65545, 76046, 87547, 98148, 09049, 21641, 87744, 62145
TRANSPARENT VIDEO SYSTEM.....	39241
TRIAx.....	56145, 34043, 45644, 54345, 10441, 10241
TV86.....	07448
TVA.....	48643, 59544
ULTIMATE TV.....	49441, 54642
UNIDEN.....	70144
UNIKA.....	41241, 50342, 88045
UNITED.....	17048
UNITED CABLE.....	66643
UNIVERSAL.....	41241, 67443, 88045
NOVAPLEX.....	91349
NOVUS.....	46843, 65642
NOW TV.....	97346
NSC.....	07448
OAK.....	27641
OI.....	37641
OMEGA.....	24941
OMEGASAT.....	24941
OPENBOX.....	68245, 39142

VISION.....	67445
VISIONETICS.....	08947
VISIONTEC.....	93349
VIVO.....	37241
VIVO.....	29641, 77943
VTECH.....	37949
VTR.....	65642
WADECOM.....	86346
WD (WESTERN DIGITAL).....	20941
WEB.....	65344, 80145
WIDOPENWEST.....	25441
WOW.....	34842
XFINITY.....	34541, 17141
ZENITH.....	52644, 23341, 40743, 75145, 55943, 30541, 41441, 41741, 55442, 76744, 65543, 68743
ZENITH NETWORK.....	23341
ZINWELL.....	69745, 22441
ZTE.....	23541
ZUTEST.....	38441

**Video - Accessory - Streaming Player / Vidéo - accessoire - Lecteur streaming / Accesorio Video - Reproductor de streaming**

AIRTV.....	12631
ALITICE.....	18131
APPLE TV.....	15031, 16731, 95939
ASUS.....	42434
AT&T.....	28832
BOXEE.....	24732
CHANNEL MASTER.....	12631
DIGITAL STREAM.....	33333